



How to convert original record files into AVI format?


1. Click the player icon by right key of mouse. And run it by administrator.




2. Import recorded video file in player list.



3. Click set up icon and then “convert AVI”




4. Please set up the convert file time less than 1 hour. See below picture, if the start time is 4:46:31, please set the stop time earlier than 5:46:30. So, the file length will less than 1 hour. And then, click start.



Attention: Please do not change the output folder or it may cause unexpected problem.

5. After convert finished, go to the folder to got the converted files.



	20181126_044631_CH1	2018/12/4 13:53	AVI 文件
	20181126_044631_CH2	2018/12/4 13:53	AVI 文件
	20181126_044631_CH3	2018/12/4 13:53	AVI 文件

Attention: if the converted files can not be played back, try to convert it again.

KEY POINT:

1. **Run player by administrator**
2. **Set convert file length less than 1 hour.** In default setting, if there has 6 imported files and the total recording time is 8 hours, the converted file length will be 8 hours too, but it has only 1 file. In this case, the converted file may have problem such as convert failed, or recording time, frame lost.